



Fitting Instructions for RAD0110BK/TI Radiator Guard
SUZUKI BANDIT 650 2010



In This Kit There Should Be
1x Radiator Guard (RAD0110BK)
2x 100mm Lengths of self adhesive Foam

- To fit the radiator guard to the bike cut the foam strip provided into 10mm wide pieces and stick them to the back of the radiator guard frame, so that they sit between the radiator guard and the radiator.
- Undo and remove the two upper radiator-mounting bolts as arrowed above.
- Undo and remove the lower radiator-mounting bolt as arrowed above.
- Offer the radiator guard up to radiator and secure using the three original bolts

ISSUE 1 28/07/2011 (NSY)

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing
Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



FRANCE

Instructions de montage de la protection de radiateur

RAD0110BK/TI

SUZUKI BANDIT 650 2010

Ce kit contient

1x Protection de radiateur (RAD0110BK-TI)

2x bandes de mousse

- Pour fixer la protection de radiateur sur la moto, vous devez couper des morceaux de mousse de 10 mm et les coller sur l'arrière de l'armature de la protection (de manière à ce qu'ils soient positionnés entre le radiateur et la protection R&G).
- Dévisser et enlever les deux vis de fixation du radiateur (fixations hautes)
- Dévisser et enlever la vis de fixation du radiateur (fixation basse)
- Placer la protection et utilisez les 3 vis de fixation d'origine pour maintenir la protection sur la moto.

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



Montageanleitung für den RAD0110BK/TI Kühlerschutz
SUZUKI BANDIT 650 Modell 2010



Dieser Kit beinhaltet:
1x Kühlerschutz (RAD0110BK)
2x 100mm selbstklebende Schaumstoffstreifen

- Um den Kühlerschutz am Motorrad zu montieren, schneiden Sie zuerst die mitgelieferten Schaumstoff-Streifen in 10 mm breiten Streifen und kleben Sie diese auf der Rückseite des Kühlerschutzrahmens, so dass sie zwischen dem Kühlerschutz und dem Kühler angebracht sind.
 - Lösen und entfernen Sie die zwei oberen Montageschrauben für den Kühler (oben im Bild).
 - Lösen und entfernen Sie die untere Montageschraube für den Kühler (unten im Bild).
- Den Kühlerschutz anbringen und mit den drei Originalschrauben befestigen.